## Assembly Instructions

Adjustable Mobile Hygiene Shield AMHS









in USA



l I Shi

## Hardware & Part Llst



## Additional Tools Required







Discounts



Assembled

in USA







Attach Casters to the Roller base as shown, press fit them until flush with base. Repeat this step on the 5 other sides.





Press fit the upright extension into the roller base. Roller base hole is tappered, press firmly until locked it stops.

Roller Base



Upright Extension











in USA



Pull back pullpin and insert to desired height. Pullpin will lock into slot and align itself.





Upright Extension







Attach the Acrylic Shield to the Shield Brackets by inserting the Phillips Bolts through the Acrylic Shield and Upright extension Shield Brackets. Once in place, insert the Phillips Bolts from the other side and tighten the Acrylic Shield in place.









Discounts



Assembled in USA