

ASSEMBLY INSTRUCTIONS

Sneeze Guard
Personal Protection Shield - PPS

EXPLODED DIAGRAM



1 Remove protective cover from the Acrylic Panel and insert it into the slot in the Suction Cup Foot.

2 Insert Bolts through the Acrylic Panel and Suction Cup Foot and fasten with Cap Nut.

NOTE:

Wood Screws are also provided for a more permanent installation.

To install with Wood Screws, simply untighten the Cap Nuts above the

Suction Cups and remove both.

Drill Wood Screws directly into surface through the holes on the Foot.

PARTS

<p>Acrylic Panel</p>  <p>Qty: 1</p>	<p>Suction Cup Foot</p>  <p>Qty: 2</p>	<p>Cap Nut</p>  <p>Qty: 4</p>	<p>Carriage Bolt</p>  <p>Qty: 4</p>	<p>Wood Screws (optional)</p>  <p>Qty: 4</p>
---	---	--	---	---