How to Clean Your Acrylic Screen



Our Sneeze Guards are made to have minimal care and maintenance. See steps below to keep your acrylic screen in great condition time-after-time of use.

Step 1: Clear any loose debris or dust from surface with soft cloth, preferably micro-fiber or cotton.

Step 2: Use soft damp cloth to gently clean acrylic. DO NOT use Windex, ammonia or any type of solvent to clean the surface. Scouring compounds and chemicals can possibly scratch the acrylic surface and break down the acrylic causing it to appear cloudy and/or streaked.

• DO NOT use Scotch Brite pads, scouring pads or brushes, as these can cause scratches if too much force is applied.

Step 3: For more stubborn soiling, use a soft sponge and common plastic cleaner or liquid cleaner (without scourer) available at your local grocer.

Thank you for your purchase. Enjoy your new Sneeze Guard!

For additional information please contact us.