

ECONOTUBE FABRIC DISPLAY

1. Connect



Connect the 3 pc. bungee linked tubes together.

2. Press



Press down on push cap then insert tube into opposite end.

5. Connect bottom tube



Connect numbered tubes together starting with the top tube.




Connect numbered tubes together with the bottom tube.

3. Snap



Push cap will snap when tube is inserted. Repeat for one pair.

6. Insert middle support bar



Insert one end at a time until middle support bar slips into place.

7. Connect feet.

4. Connect top tube.



Connect both feet to the bottom of the frame



Keep each foot offset with the thinnest side on the outside.

8. Frame is complete.



Frame is ready for graphic installation.

9. Drape and Pull



om of graphic over the top of the

Drape bottom of graphic over the top of the frame. Pull graphic all the way down.





Zip underneath the bottom support pole, maximizing fabric tension.

