



5FT CASITA CANOPY UV PRINT

OUTDOOR BANNER STAND

PRODUCT CODE: CAS-5FT



on frame on graphic



Optional Rope & Stakes w/Bag



Optional Water Base



Crank for peak adjustment



Optional Flag Mount



Optional Sand Bag



Standard Travel Bag



Optional Bag With Wheels



Optional La Caja Hardcase

PRODUCT DESCRIPTION

Our Casita Canopy Tents™ are an excellent way to provide shade during outdoor events. The graphic is printed on special water-resistant UV-cured printing process. Finished prints appear shiny and vivid and have added protection against natural elements. This canopy has a 5' x 5' footprint with five different height settings on the legs. Each square leg is 32mm thick.

| | |
|-------------------------|-----------------------------|
| DISPLAY DIMENSIONS | 59.75"W x 103.5"H x 59.75"D |
| MIN. HEIGHT | 69"H |
| MAX. HEIGHT | 103.5"H |
| LOWEST SETTING TO PEAK | 90.75"H |
| FLOOR TO LOWEST SETTING | 22.5"H |
| GRAPHIC DIMENSIONS | 60.25"W x 49"H |

GRAPHIC MATERIAL

UV Fabric (water resistant)

GRAPHIC FINISHING

Hemmed around sides and bottom edges.

DISPLAY CONSTRUCTION

Aluminum frame (Hex leg thickness: 32mm)

SHIPPING WEIGHTS & DIMENSIONS

| | |
|---------------------|-------------------|
| Shipping Weight | 39 lbs |
| Shipping Dimensions | 50"L x 9"W x 19"H |

LARGE QUANTITY FREIGHT

| | |
|------------------|---|
| Freight Shipping | 28 boxes per 50"L x 40"W x 74"H skid |
| Freight Weight | 1092 lbs (frame only) 1126 lbs (frame & graphic) |

GRAPHIC TURN AROUND TIME

4 business days after proof approval (up to 2 sets)

AVAILABLE ACCESSORIES

| | |
|---------------------|-------------------|
| Rope | Sand Bag |
| Stakes | La Caja Hard Case |
| Flag Holder | Travel Bag Wheels |
| AVAILABILITY | CA Only |
| WIND RATING | 20 mph |

5FT CASITA CANOPY UV PRINT

OUTDOOR BANNER STAND

PRODUCT CODE: CAS-5FT

PARTS LIST



(qty 1) Canopy Frame Frame



(qty 1) Travel Bag

5FT CASITA CANOPY UV PRINT

OUTDOOR BANNER STAND

PRODUCT CODE: CAS-5FT

SET UP INSTRUCTIONS

Step 1

Take your frame and slightly expand it open to expose the corner bars.



Step 2

Take your canopy graphic and place it on top of the frame.




Step 3

Adhere each corner of the canopy to each corner of the frame. Inside each corner of the canopy, there is a strip of loop Velcro sewn to it and each corner of the frame has a strip of hook Velcro.



Step 4

With the canopy securely in position, expand the frame until the corner latches lock into place.




Step 5

Increase the height by extending the lower legs.



Step 6

Pull each leg down until the latch locks into place.



Step 7

Locate the spindle under the canopy, in the middle of the frame. Pull the lever out and rotate to extend the upper peak pole. The dome cap will push out the canopy creating tension to flush out any loose areas.



Step 8

The install is complete.

